

DTC 1: A PROBLEM IN THE BLOWER MOTOR CIRCUIT

1. Check the No. 56 (40A) fuse in the under-hood fuse/relay box, and the No. 3 (7.5A) fuse in the driver's under-dash fuse/relay box.


Are the fuses OK?

YES - Go to step 2.

NO - Replace the fuse(s), and recheck.

2. Connect the No. 2 terminal of the blower motor 2P connector to body ground with a jumper wire.

BLOWER MOTOR 2P CONNECTOR



Wire side of female terminals

G01465649

Fig. 18: Connecting The No. 2 Terminal Of The Blower Motor 2P Connector To Body Ground With A Jumper Wire

3. Turn the ignition switch ON (II).


Does the blower motor run at high speed?

YES - Go to step 4.

NO - Go to step 17 .

4. Turn the ignition switch OFF.
5. Disconnect the jumper wire.
6. Disconnect the power transistor 5P connector.
7. Check for continuity between the No. 5 terminal of the power transistor 5P connector and body ground.

POWER TRANSISTOR 5P CONNECTOR



Wire side of female terminals

G01465650

Fig. 19: Checking For Continuity Between The No. 5 Terminal Of The Power Transistor 5P Connector & Body Ground


Is there continuity?

YES - Go to step 8.

NO - Check for an open in the wire between the power transistor and body ground. If the wire is OK, check for poor ground at G401.

8. Connect the No. 4 and No. 5 terminals of the power transistor 5P connector with a jumper wire.

POWER TRANSISTOR 5P CONNECTOR



Wire side of female terminals

G01465651

Fig. 20: Connecting The No. 4 & No. 5 Terminals Of The Power Transistor 5P Connector With A Jumper Wire

9. Turn the ignition switch ON (II).

Does the blower motor run at high speed?


YES - Go to step 10.

NO - Repair open in the wire between the power transistor and the blower motor.

10. Turn the ignition switch OFF.
11. Disconnect the jumper wire.
12. Disconnect the heater control panel 30P connector.
13. Check for continuity between the No. 3 and No. 4 terminals of the heater control panel 30P connector and

body ground individually.

HEATER CONTROL PANEL 30P CONNECTOR



Wire side of female terminals

G01465652

Fig. 21: Checking For Continuity Between The No. 3 & No. 4 Terminals Of The Heater Control Panel 30P Connector & Body Ground

Is there continuity?

YES - Repair any short to body ground in the wire(s) between the heater control panel and the power transistor.

NO - Go to step 14.


14. Check for continuity between the following terminals of the heater control panel 30P connector and power transistor 5P connector.

HEATER CONTROL PANEL 30P CONNECTOR-TO-POWER TRANSISTOR 5P CONNECTOR CONTINUITY CHART

| Heater Control Panel 30P Connector Terminal | Power Transistor 5P Connector Terminal |
|---|--|
| No. 3 | No. 1 |
| No. 4 | No. 3 |

HEATER CONTROL PANEL 30P CONNECTOR

Wire side of female terminals

**POWER TRANSISTOR 5P CONNECTOR**

Wire side of female terminals

G01465653

Fig. 22: Checking For Continuity Between Terminals Of The Heater Control Panel 30P Connector & Power Transistor 5P Connector

Is there continuity?

YES - Go to step 15.

NO - Repair any open in the wire(s) between the heater control panel and the power transistor.

15. Reconnect the heater control panel 30P connector.
16. Test the power transistor (see **POWER TRANSISTOR TEST**).


Is the power transistor OK?

YES - Check for loose wires or poor connections at the heater control panel 30P connector and at the power transistor 5P connector. If the connections are good, substitute a known-good heater control panel, and recheck. If the symptom/indication goes away, replace the original heater control panel.

NO - Replace the power transistor.

17. Disconnect the jumper wire.
18. Disconnect the blower motor 2P connector.
19. Measure the voltage between the No. 1 terminal of the blower motor 2P connector and body ground.

BLOWER MOTOR 2P CONNECTOR



Wire side of female terminals

G01465654

Fig. 23: Measuring The Voltage Between The No. 1 Terminal Of The Blower Motor 2P Connector & Body Ground

Is there battery voltage?

YES - Replace the blower motor.

NO - Go to step 20.

20. Turn the ignition switch OFF.
21. Remove the blower motor relay from the under-hood fuse/relay box, and test it (see **FUSES & CIRCUIT BREAKERS**).


Is the relay OK?

YES - Go to step 22.

NO - Replace the blower motor relay.

22. Measure the voltage between the No. 4 terminal of the blower motor relay 4P socket and body ground.

BLOWER MOTOR RELAY 4P SOCKET




G01465655

Fig. 24: Measuring The Voltage Between The No. 4 Terminal Of The Blower Motor Relay 4P Socket & Body Ground

Is there battery voltage?


YES - Go to step 23.



NO - Replace the under-hood fuse/relay box.

23. Turn the ignition switch ON (II).
24. Measure the voltage between the No. 1 terminal of the blower motor relay 4P socket and body ground.

BLOWER MOTOR RELAY 4P SOCKET



G01465656

Fig. 25: Measuring The Voltage Between The No. 1 Terminal Of The Blower Motor Relay 4P Socket & Body Ground

Is there battery voltage?

YES - Go to step 25.

NO - Repair open in the wire between the No. 3 fuse in the driver's under-dash fuse/relay box and

the blower motor relay.

25. Turn the ignition switch OFF.
26. Check for continuity between the No. 2 terminal of the blower motor relay 4P socket and body ground.

BLOWER MOTOR RELAY 4P SOCKET




Fig. 26: Checking For Continuity Between The No. 2 Terminal Of The Blower Motor Relay 4P Socket & Body Ground

Is there continuity?

YES - Repair open in the YEL/BLK wire between the blower motor relay and the blower motor.

NO - Check for an open in the wire between the blower motor relay and body ground. If the wire is

2003 Honda Pilot LX

2003-04 ACCESSORIES & EQUIPMENT' Heating/Air Conditioning - Pilot

OK, check for poor ground at G201.

| | | |
|--|--|--|
| | | |
|--|--|--|