


[Select Vehicle](#) | [New TSBs](#) | [Technician's Reference](#)Component Search:  [Conversion Calculator](#)[1999 Mercedes Benz Truck ML 430 \(163.172\) V8-4.3L \(113.942\)](#)[Vehicle Level](#) → [Accessories and Optional Equipment](#) → [Keyless Entry Transmitter](#) → [Service and Repair](#) →
[AR80.35-P-4215GH Synchronize Transmission Signal of Radio Remote Control](#) ←

AR80.35-P-4215GH Synchronize Transmission Signal of Radio Remote Control

[Notes](#)

Synchronize Transmission Signal Of Radio Remote Control



NOTE: If it is not possible to lock or unlock the vehicle, a synchronization of the locking system can be necessary. The reading-in process must be carried out within **10 seconds** .

- 1 Insert remote control key into ignition switch and rotate in position 2
- 2 Remove key and press lock button (2) and hold pressed, while simultaneously pressing the unlock button (3) five times.
- 3 Release buttons and then press one of the two buttons once

[Terms of Use](#)